



## CHECK-LIST TRITON

<b>Scrubber / Canister</b>	
Filling of Canister	
2 internal canister O-rings control	
close + canister marking	
<b>Counter-lungs</b>	
exhale counter-lung fitting	
inhale counter-lung fitting	
canister / counter-lung connection	
<b>Loop</b>	
Mouth-piece Visual control	
check mushroom	
Loop / Counter-Lung connection	
<b>Gas line</b>	
ADV / exhale counter-Lung connection	
Tank / first stage connection	
<b>Electronic</b>	
Cells housing / inhale counter-lung connection	
<b>positive Test / negative Test</b>	
positive test (counter-lung position control) 2min	
Negative test 2min	
<b>PpO2 Display</b>	
Turn on display	
Battery check	
<b>freedom computer (Optional)</b>	
Turn on freedom (optionnal)	
Battery check (optionnal)	
<b>Oxygen</b>	
Oxygen tank check O2 %	
Oxygen tank pressure check	
<b>Calibration</b>	
Open the over-pressure valve	
PpO2 display calibration	
Freedom calibration (Optional)	
<b>Diluent</b>	
Diluent tank check O2 % (He%)	
BCD connector diluent / ADV connection	
ADV operating control	